

Cleaning the Air Conditioner Drip Tube



Lift the front of the air conditioner off.



Pull the air filter off from the front of the condenser.



The drip pan is located under the condenser. Remove any water that may have collected in the drip pan.



Tygon tubing runs from the drip pan into the drain. Loosen the band clamp with a screwdriver to remove the tubing. Run the tubing under the faucet to clean the inside of the tube. Repeat these steps each year before you start using your air conditioning.